


# KNOW YOUR MATERIAL


Fatigue Property Mapping<sup>™</sup> characterization protocols systematically measure the factors that govern durability. The resulting engineering parameters are ready to use with durability simulation codes including Endurica CL<sup>™</sup>, Endurica DT<sup>™</sup>, Endurica EIE<sup>™</sup>, Endurica MP<sup>™</sup>, and fe-safe/Rubber<sup>™</sup>. These powerful and efficient tests show how your rubber part endures under realistic operating conditions. Begin with the Core Fatigue and Hyperelastic modules, then add on the items you need to get the physics just right in your analysis.

Hyperelastic Module
Simple, planar, and equibiaxial tension, Mullins effect

Core Fatigue Module
Fully relaxing behavior from both nucleation and fracture mechanical perspectives



### **GET DURABILTY RIGHT WITH ENDURICA TRAINING**






Learn the essential principles and practices of material characterization for fatigue life prediction, and strategies and procedures for planning effective fatigue test programs as well as making effective use of crack nucleation and fracture mechanics tools. The Characterizing Elastomer Fatigue Behavior for Analysis and Engineering workshop includes lectures to thoroughly understand the science behind Endurica's workflow and software solutions PLUS demos from Axel Physical Testing Services lab to fully illustrate the complete material characterization process.


### **Course Objectives**

- Know the physics and factors that govern the fatigue behavior of rubber
- Use accurate models and efficient procedures to characterize fatigue behavior
- Take advantage of test strategies that minimize risk and maximize productivity
- Use crack nucleation and fracture mechanics approaches effectively
- Use characterization to inform accurate fatigue calculations
- Use characterization to diagnose and solve development issues

More details at: <a href="https://endurica.com/characterizing/">https://endurica.com/characterizing/</a>







Learn the Endurica software workflows to virtually evaluate fatigue performance and solve design issues at the concept stage. Attendees have returned to their firms and revolutionized their design processes by using the software to diagnose and solve fatigue issues.


### **Course Objectives**

- Understand key principles governing fatigue in elastomers.
- Select and specify material models that accurately describe elastomer behavior.
- Apply fatigue analysis workflows for:
  - Infinite life analyses
  - Safe life analyses
  - Damage tolerant analyses
- Successfully solve durability issues using Endurica Software (CL, DT and EIE)

More details at: https://endurica.com/rubber-analysis/

# **HYPERELASTIC MODULE – REQUIRED TEST**

### Stress-Strain Behavior






- simple tension, slow cyclic loading, raw data
- planar tension, slow cyclic loading, raw data
- biaxial tension, slow cyclic loading, raw data
- 5 strain levels
- number of slabs needed for test: 4

#### Use with


- Ogden hyperelastic law
- Mullins/Ogden Roxburgh
- and other hyperelastic laws on request

### **Analysis and Reporting / Deliverables**

- identification of a suitable hyperelastic function and parameters for FEA
- identification of parameters for specifying Mullins effect in ABAQUS, ANSYS or MARC
- unit cube validation and stability check



Typical hyperelastic law fit to stress-strain curves measured in simple (blue), planar (green) and equibiaxial (red) tension.



Typical Mullins law fit to cyclic stabilized stress-strain curves.

**FPM-H Hyperelastic Module** completed at lab ambient temperature (23°C) **\$2,100** 

Additional Options

FPM-HV Volumetric Compression Add-on to Hyperelastic Module

Useful for specifying dilatational behavior of elastomers in highly confined deformation states. Requires 1 additional slab. Recommended when p / K > 5%

FPM-H-TEMP Temperature Upcharge for non 23°C Hyperelastic Module Indicate temperature with range of -40°C to 150°C

\$925

\$475

24-JUL-2025 <u>www.endurica.com</u> Page 3 of 19

### **FULLY RELAXING MODULE – REQUIRED TEST**

### **Fatique Behavior**

This module is a pre-requisite for any fatigue analysis.


The Core Module gives the basic fatigue crack growth rate curve as well as the strain-life curve and crack precursor size.

### **Experiment Overview**

- static tearing
- fatigue crack growth (20 hour procedure)
- cyclic simple tension to rupture, 2 strain levels
- number of slabs needed for test: 5

### **Analysis and Reporting / Deliverables**

- critical tearing energy  $T_c$
- tensile strain, stress, energy at break
- Thomas Law fatigue crack growth rate curve and its parameters  $r_c$  and F
- crack precursor size co calculation and sensitivity analysis
- computed strain-life, stress-life, and energy-life fatigue curves




Typical crack tip images collected during fatigue testing. Each contour shows the crack tip shape at a given number of cycles. Colors indicate time/cycles, with blue at the beginning of the test, and deep red at the end.


Use with

Thomas Law Lake-Lindley

Table Lookup



Fatigue crack growth rate observations and model fit parameters.



Crack nucleation experiments overlaid with computed strain-life curve corresponding to crack precursor size  $c_0$ . Dotted lines show the effect of crack precursor size variation on the strain-life curve.

FPM-C

## Fully Relaxing Fatigue - Core Module

\$7,750

\$1,400

completed at lab ambient temperature (23°C) fully relaxing (R = 0) conditions for all fatigue tests

Additional Option

## FPM-CORE-TEMP Temperature Upcharge for non 23°C Hyperelastic Module

Indicate temperature with range of -40°C to 150°C

24-JUL-2025 www.endurica.com Page 4 of 19

### **INTRINSIC STRENGTH MODULE**

Required for safety factor/infinite life/fatigue limit analysis

Recommended for cases with fatigue life longer than 10<sup>6</sup> cycles

FPM

This module measures the material's intrinsic strength – the minimum energy release rate required to produce crack growth. Operation below this limit does not supply sufficient energy to grow a crack so the intrinsic strength is also called the endurance limit. Use this module when the material is expected to serve for a very large number of cycles.

### **Experiment Overview**


- cutting force vs. strain, minimum 3 strain levels
- number of slabs needed for test: 3


### **Analysis and Reporting / Deliverables**

- · cutting vs. tearing curve
- cutting energy vs. strain curve
- intrinsic strength To

#### **Use with**

- Safe-life safety factor analysis
- Lake Lindley Law





The intrinsic strength minimizes the sum of the tearing and cutting energies.

The intrinsic strength is the lower bound of the fatigue crack growth rate curve.

FPM-IS

Intrinsic Strength Module completed at lab ambient temperature (23°C)

\$2,445

### **NON-RELAXING FATIGUE MODULE**

Recommended for cases where cyclic minimum loading is greater than zero and material may strain crystallize

Test is run under a range of nonrelaxing (R > 0) conditions

### Note: It is required to run FPM-C in order to run this Module.


Under nonrelaxing loads, some elastomers exhibit enhanced fatigue life / slowed crack growth due to strain crystallization effects. The effect is measured using crack arrest experiments in which a crack growing initially under fully relaxing loads is gradually operated under increasingly nonrelaxing loads. This information is required when constructing rubber's Haigh diagram for a crystallizing material.

### **Experiment Overview**

- fatigue crack growth arrest procedure with minimum strain sweep
- number of slabs needed for test: 1

### Analysis and Reporting / Deliverables

- crack arrest history c(N) for nonrelaxing cycles
- strain crystallization functions F(R) and x(R)
- Haigh diagram showing sensitivity to minimum strain of crack nucleation life



At left, Crack tip images obtained during crack arrest experiments.

Red images show the crack tip while growing under fully relaxing conditions.

Blue images show the crack tip while growing under nonrelaxing conditions.

At right, Typical strain-crystallization function x(R), showing dependence on the degree of nonrelaxation ratio R = Tmin / Tmax (where Tmin and Tmax are the energy release rate cycle extremes).


R 0.7 0.6 0.6 0.6 0.4 0.4 0.4 0.4

0.5 0.6

0.8

0.2

0.1



At left, Typical Haigh diagram for simple tension / compression loading, computed based on crack growth measurements and crack precursor size inferred from

nucleation experiments. Contours are colored and labeled according to the base 10 logarithm of the fatigue crack nucleation life.

FPM-NR Non-Relaxing Fatigue Module at 23°C

\$3,000

Additional Option FPM-NR-TEMP

Temperature Upcharge for non 23°C Non-Relaxing Module Indicate temperature with range of -40°C to 150°C

\$850

24-JUL-2025 <u>www.endurica.com</u> Page 6 of 19



Mars-Fatemi Strain Crystallization Law

X(R) Strain Crystallization Law

Use with

### **RELIABILITY MODULE**

Recommended when probability of failure needs to be estimated.



If ordered with FPM-C, includes analysis of strain life curve dependence on probability of occurrence.

The Reliability Module characterizes the rate of occurrence of crack precursors of a given size. This information is useful for estimating likely strength or fatigue failure rates for quality/warranty applications.

### **Experiment Overview**


- 50 simple tension pull-to-failure experiments
- static tearing, 3 replicates
- number of slabs needed for test: 10


#### Use with

- Reliability estimates
- Weibull distribution

### Analysis and Reporting / Deliverables

- summary statistics for pull to failure (strain, stress, energy at break)
- calculation of crack precursor size distribution c<sub>0</sub>
- Weibull distribution parameters relating frequency of occurrence to size of crack precursor





Typical Weibull analysis results showing cumulative and probability density distributions for crack precursor size.











FPM-RL Reliability Module (23°C)

\$3,450

# THERMAL EFFECTS MODULE - BASIC

Recommended for cases with self-heating or thermal gradients.

User gives 2 (additional to FPM-C) temperatures between -40°C & 150°C.

It is required to run FPM-C in order to run this Module.



The basic thermal module produces information useful for computing heat generation rate and crack growth rate law sensitivity to temperature. Use for cases involving significant self-heating and/or thermal gradients (ie  $\Delta\theta > 25$ °C).

### **Experiment Overview**


- static tearing raw data at 2 temperatures (in addition to the temperature run in FPM-C)
- cyclic stress strain raw data at 1 temp., 1 frequency, 5 strain levels
- number of slabs needed for test: 3

#### Use with


- Power law strain amplitude hysteresis model
- Terziyski-Kennedy temperature law
- Exponential fatigue crack growth temperature sensitivity

### Analysis and Reporting / Deliverables

- heat generation law parameters describing dependence of hysteresis on strain
- tear strength vs. temperature
- crack growth rate law temperature sensitivity coefficient C







Dependence of tearing energy  $T_c$  on specimen temperature.

### FPM-TB Thermal Effects Module - Basic

\$4,995

Additional Options

FPM-TB-THRM Thermal Conductivity, Specific Heat, and Density

\$1,050

# THERMAL EFFECTS MODULE - ADVANCED

For improved accuracy in structural and heat transfer analyses of self-heating and thermal gradient effects.

Note: FPM-TB is required as a prerequisite



The advanced thermal module is an add-on to the basic module. It enables greater accuracy and completeness in the representation of temperature and frequency effects in structural and thermal models.

### **Experiment Overview**


- static tearing raw data at 2 more temperatures (in addition to the 3 temperatures already collected in FPM-C and FPM-TB)
- cyclic stress strain raw data at 3 temperatures and 3 frequencies
- thermal conductivity, specific heat & density measurements
- thermal expansion measurement
- number of slabs needed for test: 3

#### **Use with**


- Powerlaw strain amplitude hysteresis model
- Terziyski-Kennedy temperature and frequency model
- Exponential fatigue crack growth temperature sensitivity
- Table lookup temperature model

### Analysis and Reporting / Deliverables


- heat generation law parameters describing dependence of hysteresis on strain, rate, and temperature
- tear strength vs. temperature
- · fatigue crack growth rate law temperature look up table
- coefficient of thermal expansion




Dependence of hysteresis *H* on max strain, temperature and frequency.



Thermal transport properties are measured using transient plane source method.



Dependence of tearing energy  $T_c$  on specimen temperature.



Thermal expansion is measured using thermomechanical analysis (TMA).

### FPM-TA Thermal Effects Module - Advanced

\$9,975

### THERMAL EFFECTS MODULE - K/WLF

This module is used to determine the strain, temperature and frequency dependence of the viscoelastic storage and loss modulus for use in thermal-mechanical analysis with temperature effects and energy dissipation, or self-heating considerations.



The K/WLF module is named for Kraus and for Williams-Landel-and-Ferry, two representations used to describe viscoelastic DMA (Dynamic Mechanical Analysis) measurements. Supports thermal-mechanical workflows for product temperature and energy dissipation analysis.

### **Experiment Overview**


- low Strain Frequency Sweeps at 3 temperatures
- low Strain Temperature Sweep
- Strain Sweep initial and repeat at specified temperature and frequency
- optional thermal conductivity, specific heat and density
- three replicates of each test
- number of slabs needed for test: 4


#### Use with

- Kraus hysteresis law
- WLF temperature / rate law
- Lookup table hysteresis law

### **Analysis and Reporting / Deliverables**

- Kraus fit for strain amplitude dependence of storage and loss modulus.
- WLF shift and master curve for storage and loss modulus to describe response over a wide range of temperatures and frequencies.
- look-up tables for master curve representation and Kraus parameter fits for input to simulation codes.
- formatted input for analysis codes and final report





FPM-TM-KWLF	Thermal Effects Module – K/WLF	\$3,650
Additional Options FPM-TM-THRM	Thermal Conductivity, Specific Heat, and Density Requires 1 additional slab.	\$1,050
FPM-TM-TEMP	<b>Temperature Upcharge for +2 Temperatures</b> For frequency sweeps	\$600

### **AGEING MODULE - BASIC**

Recommended for cases with fatigue life longer than 10<sup>6</sup> cycles, and when ageing must be taken into account for a specific aged condition.

Note: It is required to run FPM-IS in order to run this Module.

The ageing module is recommended when the material operates below the endurance limit. Although cracks may not grow due to mechanical fatigue, the material properties may still evolve with exposure to heat history. The results of this module enable the user to compute fatigue performance considering both unaged and aged material properties.

### **Experiment Overview**

- ageing in oven at 1 client-specified time and temperature
- static tearing raw data, unaged vs. aged
- cutting force raw data, unaged vs. aged
- number of slabs needed for test: 5


### **Analysis and Reporting / Deliverables**

- stiffness, unaged vs. aged
- · cutting vs. tearing curve, unaged vs aged
- intrinsic strength To, unaged vs aged
- tearing energy  $T_c$ , unaged vs aged
- fatigue threshold strain, stress, energy, unaged vs aged (when ordered with FPM-C)

Use with

Simple comparison of unaged and specified

aged behavior



Comparison of unaged and aged stiffness and crack growth rate law parameters.

### FPM-AB Ageing Module - Basic

\$4.975

24-JUL-2025 <u>www.endurica.com</u> Page 11 of 19



# AGEING MODULE – MASTER CURVE

Recommended for cases with fatigue life longer than 10<sup>6</sup> cycles, and when ageing must be taken into account.

Note: It is required to run FPM-IS in order to run this Module.

The extended life module is recommended when the material operates below the endurance limit. Although cracks may not grow due to mechanical fatique, the material properties may still evolve with exposure to heat history.


fatigue, the material properties may still evolve with exposure to heat history. A series of oven ageing experiments is used to develop master curves showing the evolution of stiffness, intrinsic strength, and fracture strength with time. The protocol also produces an estimate of the activation energy of the Arrhenius rate law describing the time-temperature dependence of ageing in the material.

### **Experiment Overview**

- ageing in oven at 3 temperatures for 3 time periods: 3 days, 10 days, 30 days
- static tearing raw data, 3 ageing periods x 3 ageing temperatures
- cutting force raw data, 3 strain levels x 3 ageing periods x 3 ageing temperatures
- number of slabs needed for test: 30

### **Analysis and Reporting / Deliverables**

- cutting vs. tearing curve at each aged condition
- intrinsic strength  $T_0$  vs. ageing master curve
- tearing energy T<sub>c</sub> vs. ageing master curve
- Arrhenius activation energy, E<sub>a</sub>
- fatigue threshold strain, stress, energy vs. ageing curves (when ordered with FPM-C)
- parameters specifying ageing time and temperature dependence of T<sub>0</sub> and T<sub>c</sub>
- extrapolation of ageing effects to longer timescales for an application-specific temperature



Use with

Arrhenius ageing law

Ageing experiments over a 3x3 matrix of oven temperature and time settings are used to develop accelerated degradation curves. Based on the Arrhenius rate law, the accelerated degradation curves are compiled into a master curve for a specific reference temperature (here, the reference temperature is 23° C).

FPM-AM Ageing Module – Master Curve

\$14,850

### CREEP CRACK GROWTH MODULE

Recommended for cases involving long periods under static load Lab ambient temperature (23°C)



The creep crack growth rate module produces information useful for cases involving long-term static loads under which time-dependent crack growth (rather than cycle-dependent crack growth) may occur.

### **Experiment Overview**


- raw data from quasistatic creep crack growth procedure
- number of slabs needed for test: 1

### Analysis and Reporting / Deliverables


• creep crack growth rate curve and its parameters  $(T_q, r_q, \text{ and } F_q)$ 


### **Use with**

- Powerlaw creep crack growth model
- Table lookup creep crack growth rate law



Typical crack tip images collected during fatigue testing. Each contour represents the crack tip shape at a given number of cycles. Colors indicate time, with blue at the beginning of the test, and deep red at the end.





FPM-CR

Elastomer Fatigue Property Map - Creep Crack Growth Module \$1,615

Additional Option FPM-CR-TEMP

Elastomer Fatigue Property Map – Creep Crack Growth Module \$850 Indicate temperature with range of -40°C to 175°C

### CYCLIC SOFTENING MODULE

Recommended for cases where stiffness degradation limits durability



The cyclic softening module produces information about the rate at which stiffness evolves under cyclic solicitations. This information is useful for modeling stiffness evolution under fatigue cycles using Endurica DT's stiffness loss cosimulation feature. The experiment is run in displacement control, and it records the evolution of the peak stress with cycles.

### **Experiment Overview**


- raw data from cyclic softening procedure on simple tension strips at 5 strain levels
- number of slabs needed for test: 1

### **Analysis and Reporting / Deliverables**

- family of cyclic softening curves showing stiffness degradation rate as a function of life consumed
- curve fit to cyclic softening model

#### Use with

Cyclic softening model



### FPM-S Elastomer Fatigue Property Map – Cyclic Softening 23°C \$2,845

Additional Option

FPM-S-TEMP Temperature Upcharge for non 23°C Cyclic Softening Module \$850 Indicate temperature with range of -40°C to 175°C

### **OZONE EFFECT MODULE**

Required when rubber that has a susceptibility to ozone attack is operating in an environment with ozone.



Ozone is a trace gas that strongly reacts with some rubbers to produce surface cracking following exposure. Ozone cracking can limit useful product life, even when mechanical cycles operate below the mechanical fatigue threshold. The Endurica ozone attack testing method determines:  $\mathcal{E}_z$  the critical strain for ozone attack;  $T_z$  the critical tearing energy for ozone attack; and  $r_z$  the rate of crack growth due to ozone attack.

### **Experiment Overview**


- images of crack development on specimen
- 3 replicates
- number of slabs needed for test: 1

### Analysis and Reporting / Deliverables

- determine  $\mathcal{E}_z$  critical strain
- determine  $r_z$  ozone crack growth rate
- determine  $T_z$  critical energy for ozone attack

#### Use with

- Williams ozone attack model
- Gent-McGrath ozone attack model



Typical crack growth rate behavior and parameters under ozone attack.



Typical surface cracking after ozone attack

### FPM-O Elastomer Fatigue Property Map – Ozone Effect Module

\$950

Default exposure: 50 pphm O<sub>3</sub> concentration, 72 hrs @ room temperature 23°C

### **CHIP & CUT MODULE**

Recommended for cases where harsh or abrasive environments may cause cutting and chipping on an elastomeric contact surface.



The chip and cut module measures the material's resistance to damage from impacts with sharp surfaces. This test can be related to real-world conditions that lead to pitting and chunking of rubber surfaces. It is essential for tire tread materials and other applications subjected to wear via contact/impact with rigid, macro-scale, small-radius, convex surfaces such as stones.

### **Experiment Overview**

- Test Instrument: Coesfeld Instrumented Chip & Cut Analyzer (ICCA<sup>©</sup>)
- Indenter pushed into round rotating specimen with repeated impacts
- Experimental data recorded: Normal force, tangential force, and indentation depth as a function of time for each impact
- All tests performed at lab ambient temperature (23°C)

#### Use with

- Tire tread applications
- Belts especially in mining
- Impact damage applications

### **Analysis and Reporting**

- Test data is evaluated to determine Chip-Cut damage parameter, P, by integrating the fluctuations in tangential force. A lower value of P indicates greater resistance to chip-cut damage.
- Weight loss recorded during experiment
- Images of specimens before and after testing



Peak normal force, impact duration and frequency are specified as test inputs. Longitudinal friction force and indenter penetration are monitored during the test.



Images of test specimens show wear damage that occurred during the test. Mass loss is reported along with Coesfeld's Pparameter.

## FPM-CC-1 Basic Procedure (Recommended for Materials Development) See Chart

• 1 load case x 3 replicates per compound

### FPM-CC-5 Advanced Procedure (Recommended for Simulation)

See Chart

5 load cases x 3 replicates per compound

Provide 100 g of uncured compound per specimen to be tested, or request a quote to rent our mold to produce your own specimens.

				Load Cases		
		1	2	3	4	5
Compounds	1	550	1100	1605	2140	2675
	2	1100	2140	2400	3200	4000
nod	3	1605	2400	3600	3660	4575
Com	4	2140	3200	3660	4880	6100
	5	2675	4000	4575	6100	7625

<sup>\*</sup>Curing runs cost \$150 each and produce 6 cured specimens per run.

### **Ordering Instructions**

1) Send **Purchase Order** specifying number of materials and tests to be run, and the email address to which results should be delivered, to:

Endurica LLC jasuter@endurica.com 1219 West Main Cross, Suite 201 Findlay, OH 45840 USA

Phone: +1-419-957-0543

- 2) Test specimens are die-cut from customer-provided sheets of approximate dimensions 150 mm x 150 mm x 1-2 mm. Please see the **Fatigue Property Map Order Form** on the following page for the number of material slabs required.
  - a. Label each slab with the material identifier you want us to use in reporting.
  - b. Complete the **Fatigue Property Map Material Shipment Form** for each material and include it with your material samples.
- 3) Test execution times may vary, depending on lab backlog and Modules requested. Once testing, analysis and reporting are complete, you will receive an email from Endurica containing the analysis and summary report, and all raw data files.

#### Notes:

All results delivered via email. The raw data is delivered in an ASCII format. The analysis and summary report is delivered in PDF format.

Customer data and materials will be retained for 1 year after initial data delivery.

Purchase Order, VISA, MasterCard, AMEX, and Discover Card are accepted methods of payment.

Terms: NET 30 Days after Delivery of Final Report and Data.

Fatigue Property Map Testing Order Form Include one form for each material in shipment

Qty.	Item	Module	Customer Specifications	Slabs*	Price	Total
	FPM-H	Hyperelastic	Peak strain levels: Temperature:	4	\$2,100	
	FPM-HV	Volumetric Compression	Temperature:	1	\$475	
	FPM-H- TEMP	Temp Upcharge	Temperature:		\$925	
	FPM-C	Core Fatigue Testing	Test Temp: Test Freq:	5	\$7,750	
	FPM-CORE- TEMP	Temp Upcharge	Temperature:		\$1,400	
	FPM-IS	Intrinsic Strength		3	\$2,445	
	FPM-NR	Nonrelaxing	Test Temp: Test Freq:	1	\$3,000	
	FPM-NR- TEMP	Temp Upcharge	Temperature:		\$850	
	FPM-R	Reliability		10	\$3,450	
	FPM-TB	Thermal – Basic	Test Temps (2):	3	\$4,995	
	FPM-TA	Thermal - Advanced	Test Temps (3): Frequencies (3):	3	\$9,975	
	FPM-TM- K/WLF	Thermal - WLF	Test Temps (3):	4	\$3,650	
	FPM-TM- THRM	Thermal Conductivity, Specific Heat and Density	Temperature:	1	\$1,050	
	FPM-TM- TEMP	Temp Upcharge	Temperature 1: Temperature 2:		\$600	
	FPM-AB	Ageing - Basic	Aged / Unaged	5	\$4,975	
	FPM-AM	Ageing – Master Curve	Ageing Oven Temps (3):	30	\$14,850	
	FPM-CR	Creep Crack Growth	Test Temp:	1	\$1,615	
	FPM-CR TEMP	Temp Upcharge	Temperature:		\$850	
	FPM-S	Cyclic Softening	Test Temp:	1	\$2,845	
	FPM-S- TEMP	Temp Upcharge	Temperature		\$850	
	FPM-O	Ozone Effect	O₃ Concentration: Test Temp: Time:	1	\$950	
	FPM-CC	Chip & Cut	Number of load cases: Normal Force levels:	See test notes	See Chart	
			Total			

<sup>\*</sup> Nominal slab dimensions are 150 mm x 150 mm x 2 mm.

Customer Notes:				
Company Name:	Contact:	Email:		
Address:	Title:	Phone:		

Ship to: Endurica LLC - Attn. Joe Suter - 1219 West Main Cross, Suite 201 - Findlay, OH 45840 - USA

### **About Our Fatigue Property Mapping Service**

The service enables engineers to obtain, from a commercial source, reliable, affordable measurements suitable for use in fatigue analysis.

Training on the experimental procedures and analysis for fatigue life prediction is available. For complete information and our schedule of upcoming classes please visit www.endurica.com/training2/



Endurica LLC develops the world's most versatile and best-validated fatique life simulation system for elastomers. Through our technology and services, Endurica empowers our clients' analysis of the real-world fatigue performance of elastomers at the design stage, when the greatest opportunity exists to influence performance, and before investment in costly fatigue testing of prototypes. Endurica was founded in 2008 and received the 2020 Tibbetts Award for outstanding cutting-edge technology by the United States Small Business Administration. www.endurica.com

### **About ACE Laboratories**

The talented team of professionals at ACE Laboratories provides independent analytical and physical testing services. ACE's 200,000 square-foot, state-of-the-art, ISO/IEC 17025 accredited polymer testing laboratory is staffed by experienced technicians boasting over 200 years of combined industry experience in their professional journey to set new standards in the testing industry. https://www.ace-laboratories.com/ LABORATORIE

### **About Axel Products**

Founded in 1994, Axel Products provides testing services for engineers and analysts with a focus on the characterization of nonlinear materials such as elastomers and plastics. Data from the Axel laboratory is often used to develop material models in finite element analysis codes such as ABAQUS, Ansys, fe-safe/Rubber, Hexagon (MSC/Marc), and



LS-Dyna. Testing services are also provided to examine sealing and fatique problems, long-term thermal mechanical testing, and high strain physical testing services rate testing, www.axelproducts.com